DECODD	DDAMAIA	/ACDIIII T
RECURD	DRAWING	ASBUILI

CHELAN-DOUGLAS HEALTH DISTRICT

PARCEL IDENTIFICATION				
Permit Number		arcel #:		
Applicant's Name	Designer/E	Designer/Engineer:		
Project Address		nstaller:		
INS	TALLER CHECKLIST			
	N/A or No	Yes	emino a seridin -	
I. SEPTIC TANK	0	Ο		
>5 ft. from foundation?	0	0		
>50 ft. from all wells?	0	Ö		
>50 ft. from surface water?	O	0		
Clean out at building?	O	0		
Risers installed for tank access?	0	0		
Effluent filter installed?	0	0		
Tank water tested or sealed for water-tightn	ess? O	0	THE PARTY OF	
(Tank guarenteed watertight to invert	of outlet)			
Tank size: gallons Manufacture:	:			
II. DRAINFIELD				
>10 ft. from foundation?	0	Ο		
>5 ft. from property lines and easement line		O		
>100 ft. from all wells?	0	0		
>10 ft. from potable water lines?	0	Ō		
Laterals level to +/- 1 inch?	0	0		
Gravel clean, properly sized, and proper de	pth? O	0		
Gravel / gravelless chamber / EZ flow / subsurface drip line / other utilized? (circle one)				
Pressure Systems	·	,		
ASTM C-33 sand quality within DOH spe	ecifications?	0		
(attach sieve analysis from supplie	er)			
Head height uniform +/- 15%?	O	0		
Clean outs and observation ports installed	ed? O	0		
Orifices sized and spaced per design?	0	0		
Actual head height: feet / inch	es			
III. PUMP/PUMP CHAMBER				
Riser installed for access?	0	0		
Alarm floats tested and float heights set per	-h	0		
Tank water tested or sealed for water-tightn		0		
Pump make: Pump mode		a 71 s		
Chamber size: gal. Manufact	ure:			
Pump chamber draw-down: inches		in +/- 1/4 inch.		
Chamber gallons per inch (from manufactur	re):			
Pump controls installed and settings progra			page).	
If Yes, Pump On:n	nin/sec. Pump Off: h	rs.		
IV. NOTES/COMMENTS				
			5	

100	RECORD DRAWING (accurate to +/- 1/2 foot)					
	CHECKLIST (use 100' tape measure)	301 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1				
0	O Drainfield (DF) & manifold orientation & layout					
0	O Trench/bed dimensions and critical distances within layout					
0	O Septic/pump tank placement					
0	O Location of buildings/property lines in relationship to the tank(s)/DF					
0	O Observation ports & clean-out location					
0	O Location of all wells & roads/driveways					
0	O Undisturbed native soil between trenches/beds					
0	O North arrow					
0	O 100% Reserve area if new construction or expansion					
CAUTION: Minor adjustments to septic tank location and drainfield orientation made in the field by the installer are generally acceptable to both the Health Department and the designer, but could in certain cases compromise the viability of the system. It is the installer's responsibility to obtain prior written approval from either the Health Department or the designer before making any deviations from the design that may affect the system viability. Any deviations from the approved design must be shown above.  CERTIFICATION OF INSTALLATION						
Ins	Installer: Check the appropriate box from Row "A" and/or "B", sign	n and date the Certification				
A.	A. O I certify that I installed the system without any deviation from the design stamped "APPROVED" by "APP	ify that all the deviations from the design stamped ROVED" by Chelan-Douglas Health District (CDHD) are n above.				
в.	control panel is installed, tested, and correctly I have programed.	pressurized system, the control panel was not installed. e informed the owner that I will ensure the specificied I will be installed, tested, and correctly programmed. inform CDHD in writing when completed.				
I further certify that all information contained on this form is accurate. I understand that if the information contained herein is not accurate, there will be just cause for immediate suspension of my installers license and/or fines.						
		- 5				
rev	revised 12/10/09	Signature of Installer Date				